



©IBS
888-634-4289

1	91D0132	BURNER MAIN ANGLE ASSEMBLY - INCL. ELECTRODE AND WIRE	4
3	50000892	BURNER GASKET	4
4a	50000879	FLASH TUBE	1
5	30005717	CONSOLE w/RIVNUT ASSEMBLY	1
6	50002788	IGNITOR PUSHBUTTON	1
7	50002533	IGNITOR PLATE	1
8	50001619	IGNITOR MODULE ASSEMBLY	1
9	91D0111	HOSE REGULATOR - LP	1
N/S	20302809	HOSE PLUG ASSEMBLY - for sear burner LP/NG	1
10	50003002	BEZEL ASSEMBLY - BACKLIT	5
11	50003984	KNOB	5
13a	50004266	WIRING HARNESS	1
14	20300400	VC LIGHT KIT	1
15	91D0136	LEFT CONDIMENT TRAY	1
16	91D0137	RIGHT CONDIMENT TRAY	1
17	30005448K	SMOKER BOX KIT	1
19	20300520	ACCESSORY SHELF	1
20	30005410K	LEFT SHELF ASSEMBLY	1
21	30006022	RIGHT SHELF ASSEMBLY	1
22	50004320	TOWEL BAR	2
27	50003473	ROTISSERIE ELECTRODE WIRE	1
28	50000777	HEAT PLATE - SS	4
29	50004143	TUBE & ORIFICE ASSEMBLY 4 BURNER - LP	1
29a	50004144	TUBE & ORIFICE ASSEMBLY 4 BURNER - NG	1
N/S	50003474	CLIP FOR TUBE AND ORIFICE	1
30	50003500	ROTISSERIE BURNER ASSEMBLY	1
31	30005363	COOK GRATES	3
33	30005722	DOOR UPPER BRACE	1
34	50002033	MAGNET SNAP IN	2
35	50001845	GREASE CUP	1
36	20300395	BEZEL FOR TEMPERATURE GAUGE	1
37a	30005720K	BACK PANEL - SS	1
38	50002490	SNAP BUSHING 2IN	1

©IBS

888-634-4289

©IBS

888-634-4289

40a	30005723	DOOR ASSEMBLY - SS	2
41	50004204	HANDLE CURVED - DOORS	2
42	20300389K	SIDE PANEL RIGHT	1
43	20300390K	SIDE PANEL LEFT	1
48a	30005772	GREASE PAN	1
49a	30005711	REAR LID ASSEMBLY	1
50a	30005837	WARMING RACK	1
51	30005708K	FRONT LID ASSEMBLY - SS	1
52	50000355	HARDWARE LID SET	1
53	50000365	LID BUMPER SET (6)	1
54	30005707	LOGO ASSEMBLY	1
55	20300394	TEMPERATURE GAUGE	1
56	91D0108	ELECTRODE WIRE - MAIN	4
58	91D0107	ELECTRODE ONLY - MAIN	4
63	91D0112	CONNECTOR HOSE - NG	1
64	50002384	12 FOOT HOSE - NG	1
65	91D0134	ROTISSERIE KIT - NO SPIT ROD	1
66	30005922	BATTERY SHROUD ASSEMBLY	1
67	91D0131	ROTISSERIE MOTOR ONLY	1
68	30005630	CURVED HANDLE GRIP SET	1
70	50004255	CASTER 3IN.	2
71	50004256	CASTER 3IN. W/BRAKE	2
72	50003472	ROTISSERIE ELECTRODE	1
73	91D0140	HARDWARE BAG SIDE SHELF	1
74	20300623	HINGE 20 GA. 20.5IN. - SS	2
75	20300398	SPIT ROD 29IN	1
76	50002888	CYLINDER RETAINER - LP	1
79	91D0155	HARDWARE BAG CASTERS	1
80	50004258	GREASE CUP HOLDER	1
83	50004417	UTENSIL HOOK	3
84	30005991	SPIT ROD STORAGE BRACKET	2
85	20302816	VALVE MANIFOLD ASSEMBLY LP	1
85a	20302817	VALVE MANIFOLD ASSEMBLY NG	1
86	50000399	SPIT ROD SUPPORT BRACKET	1
87	50004275	ROTISSERIE MOTOR BRACKET	1
88	50003110	BATTERY CASE	1
89	50002914	SNAP BUSHING 3IN	1
90	50004840	ROTISSERIE FORK KIT	1
91	20300399K	CORNER POST SS	4
93	30005721	BOTTOM PANEL SS	1
94a	20304422	SEAR BURNER LP	1
94b	20304423	SEAR BURNER NG	1
95	50004650	TANK PULL OUT ASSEMBLY	1
96	20300625	ELECTRODE WIRE SEAR BURNER	1
97	20300629	CONTROL VALVE SEAR BURNER	1
98	20300630	SEAR BURNER COOK GRATE	1
99	20300645	SEAR BURNER GREASE TRAY	1
100	20301000	SEAR BURNER TOP COVER	1
101a	20300647	SEAR BURNER NOZZLE (INJECTOR) ASSEMBLY LP	1
101b	20300766	SEAR BURNER NOZZLE (INJECTOR) ASSEMBLY NG	1
102	20301001	SEAR BURNER LID KNOB	1
N/S	20300625	SEAR BURNER ELECTRODE	1
N/S	20300626	SEAR BURNER IGNITOR KIT	1
103	20304427	SEAR BURNER CONTROL KNOB	1
N/S	30005801	USER MANUAL	1
N/S	30005803	ASSEMBLY MANUAL	1
N/S	30005802	PARTS LIST	1
N/S	VCS11C4	DELUXE COVER	1
N/S	20304535	CONVERSION KIT - LP TO NG	0
N/S	20304536	CONVERSION KIT - NG TO LP	0